

Service Following Test Solution

Doewe Technologies Application Notes-009-V1.0 www.doewe.com/info@doewe.com

1. Introduction

As third-generation broadcasting technologies, DAB and DRM digital radio are now widely used in over 20 different countries or regions. Applications based on this technology are diverse, with in-car radio being one of the most typical scenarios. As the world's largest automobile exporter, China's demand for research and testing of this technology is also increasing daily.

In practical applications of in-car radio, a common issue arises: when a user travels from one service area to another, they may experience an interruption in listening due to leaving the coverage area of the original signal. To avoid this problem, replacement services available in the user's current area are utilized to ensure continuity of listening. This application is called Service Following.

In digital broadcasting, Service Following is achieved through Alternate Frequencies (AF) and Service Linking between the three modulation types: DAB, DRM, and FM. This article presents a test solution using Redwood Comm's broadcast signal generator RWC2010C, emergency broadcast tester RWC2100F, and the core functional software "Service Linking test tool".



Figure 1: Schematic Diagram of Service Following Function



2. Actual Service Following Interaction Process



The actual Service Following interaction process, shown in Figure 2, is divided into three stages.

Figure 2: Service Following Flowchart

Stage One:

Attempt to find a DAB service with the same Service Identifier (SId) within other ensemble signals in the current region. It is necessary to identify all DAB ensemble signals carrying service information "identical" to the current program. The receiver will also only return ensemble signals carrying the *same service* (i.e., same ECC and SId) as the user-selected service. In this stage, priority should be given to the ensemble frequency transmitting the service identical to the user's originally selected service.

Stage Two:

Search the database for given hard-linked services. Hard-linked services carry the *same audio content* as the user's originally selected service. The receiver under test (RUT) first establishes a DAB linkage set based on the service linking information and attempts to identify services within that set that have a hard link to the selected service. Ideally, a suitable candidate service is identified and monitored during this stage; once its suitability is confirmed, a change to that service can be allowed.

Stage Three:

Search the database for related soft-linked services. The process in this stage is identical to Stage Two. However, since soft-linked services are only *related* to the user-selected service and do not carry the *same audio content*, user manual intervention may be required when deciding whether to switch services.

These three stages are executed sequentially in a loop. If one stage fails, the process automatically proceeds to the next stage until the required signal is successfully acquired in one of the stages, after which it returns to the



3. Test Solution Introduction

The test solution provided by our company is based on the actual interaction process described in Section 2, testing the receiver under test (RUT) by simulating the entire flow. The general test method is as follows:

First, prepare the hardware connection. Connect a control PC to three RWC2010C units and one RWC2100F unit using an Ethernet cable and a switch (referred to as Device 1, Device 2, Device 3 for the RWC2010Cs, and Device 4 for the RWC2100F). Confirm the connection status of the devices on the control software. Combine the output signals from the four devices using a combiner and feed them into the car audio system under test.



Figure 3: Hardware Connection Schematic

This test setup can simulate various real-world application scenarios. Examples are provided below.

Scenario 1: Simulating switching from the original DAB ensemble signal to another DAB ensemble signal

- Device 1 emits a DAB ensemble signal at -10 dB. Device 2 emits the *same* DAB ensemble signal at -120 dB. The RUT listens to the program in Device 1's signal.
- Import a specific file into the Power Configurator to control Device 1's signal power to gradually decrease to -120 dB, and Device 2's signal power to gradually increase to -10 dB. This simulates the receiver moving from one service area to another.
- 3. Determine if the RUT's function is normal based on whether it successfully switches to the signal emitted by Device 2.

Scenario 2: Simulating switching from the original DAB service to an FM service

- Device 1 emits a DAB signal at -10 dB. Device 4 is set to emit an FM signal with the *same service content*. The RUT listens to the program in Device 1's signal.
- Import a specific file into the Power Configurator to control Device 1's signal power to gradually decrease to -120 dB, and Device 4's signal power to gradually increase from off (or low) to 0 dB. This simulates the receiver moving from one service area to another.
- 3. Determine if the RUT's function is normal based on whether it successfully switches to the signal emitted by Device 4.

Scenario 3: Simulating switching from the original DAB service to a DRM service

- 1. Device 1 emits a DAB ensemble signal at -10 dB. Device 3 emits a DRM signal containing the *same service* at -120 dB. The RUT listens to the program in Device 1's signal.
- Import a specific file into the Power Configurator to control Device 1's signal power to gradually decrease to -120 dB, and Device 3's signal power to gradually increase to -10 dB. This simulates the receiver moving from one service area to another.
- 3. Determine if the RUT's function is normal based on whether it successfully switches to the signal emitted by Device 3.

Furthermore, this test solution can simulate more complex scenarios to meet diverse customer testing requirements.

4. Software Module Introduction

The software, based on its GUI mode, can be divided into three modules: Station Settings, AF Parameter Display Window, and Power Configurator.



lork\$	pace About	OPEN WS	SAVE WS		service_linki	ng.ws									
	STATIONS	Description	. This is an	example works	pace for seamles	s linking									
-	e d w o o d _{Comm}														
ADUIO DELAY Synchronized		192.168.0	39 CON	NECT O	IP 192.168.0.	50 00	NNECT O	IP 192.168.0	.73 00	NNECT O	192.168.0	50 00	NNECT		
	meters	0	1		•		2		1	2 C X				2. 10	
	FREQ CH O		173.928	-		175.928	•	87.700	88.700	89.700	90.900	91.900	92.900	0~-10	
	LABEL(max.16)	STA-01	STA-02	STA-03	ST8-01	STB-02	STB-03	STC-01	STC-02	STC-03	STD-01	STD-02	STD-03	-2030	
1	CONTENTS AUDIO DELAY(sec)	service_linki v 1	service_linki ↓ o 2.0	leb_linking.1 ↓ 3.0	3.0	2.0	1.0	0.0	-1.0	-2.0	-3.0	-2.0	-1.0	-30~-40	
1	PID/SID	1001	1002	1003	2001	2002	2003	3001	3002	3003	4001	4002	4003	-40~-50	
	EID	1001	A001	1005	1001	B001	2005		5002		4001	4002	4005	-50~-60	
Ed	litor DAB/DRM							PM CTO			FM DTO			-70~-80	
	HIDE AF TREE	0 1 2		2 0 1 2 0 1 2				048 148 174 174 174 175 175 175 175 175 175 175 175			012 012 012		0 1 2		
		AF Parameter Tree			AF Parameter Tree			AF Parameter Tree			AF Parameter Tree				
		- AF_DAB_TO_DI - NUM - AF_00 - OTHER_ - OTHER_ - CEI - AF_SVC_TO_DI - NUM - AF 00	EID 0 FREQ 175. LONG_1	1 001 HEX 928 MHZ ERM 3	- AF_0AB_T0_0 - NUM - AF_00 - OTHER - OTHER - CEI - AF_SVC_T0_0 - NUM - AF_00	EID FREQ 17 LONG	1 A001 HEX 3.928 MHz _TERM 3 ~	← FM_RDS_0 — AF_NUM — AF_00 — AF_01 — AF_02 — AF_03 — AF_04 ← FM_RDS_1 — AF_NUM	5	5 18.700 MHZ 19.700 MHZ 19.900 MHZ 11.900 MHZ 12.900 MHZ 5	- FM_RDS_0 - AF_NUM - AF_00 - AF_01 - AF_02 - AF_03 - AF_03 - AF_04 - FM_RDS_1 - AF_NUM	8 8 9	5 17.700 MHZ 18.700 MHZ 19.708 MHZ 11.900 MHZ 12.900 MHZ 25. ¥		
PC	OWER PROFILE	RUI	N 00:00	:00 🚔 0							1	18	Show	v all	
	# TDuration(s)	STA-01	STA-02	STA-03	STB-01	STB-02	STB-03	STC-01	STC-02	STC-03	STD-01	STD-02	STD-03	SET - +	
	1 30	-10			-20			-30	-30	-30	-40	-50	-60	SET - +	
	2 60	-30			-30			-20	-20	-20	-10	-30	-40	SET - +	
	3 30	-50			-40			-10	-10	-10	-10	-30	-40	SET - +	
								0	0	0	-10	OFF		SET - +	

Figure 4: Software Display Interface

1. Station Settings

After connecting the application to each device via Ethernet, the connection status of the devices can be viewed in this module. Each device has 3 switches. The function controlled by the switches varies depending on the connected device or transmission mode. When connected to an RWC2010C in DAB or DRM mode, the switches represent 3 services within the ensemble signal; each service can be turned on or off individually. When connected to an RWC2100F, the switches represent 3 FM transmitters.Notably, an RWC2010C in DAB mode can provide up to 64 services per ensemble, and in DRM mode, one multiplex can accommodate 4 services. For ease of testing, the software configures only 3 services. Additionally, the parameters and attributes displayed in the software will differ depending on the connected device.



		DAB_A RWC2010x V	DAB 🗸	FM_B RWC2100F V FM V							
IP 1	92.168	.0.39 DIS	CONNECT	IP 192.168.	0.59 DIS	CONNECT					
	1					()					
-		174.928		91.300	92.100	92.300					
STA-C	01	STA-02	STA-03	STB-01	STB-02	STC-03					
dab_linki	ng.ı 🗸	dab_linking.r 🗸	dab_linking.1 🗸	momo.wav 🗸	momo.wav 🗸	momo.wav 🗸					
1.0	-	0.0	-1.0	2.0	-3.0	-4.0 🔹					
A00	1	A002	A003	B001	B002	B003					
		EOOA									
DAB_AT	0		s_c	FM_B TO							
S	VCO	SVC1	SVC2	PRGO	PRG1	PRG2					
DAB FM DAB FM 0				DA5 0 0 1 2							

Figure 5: Station Settings Interface

2. AF Parameter Display Window

The AF Parameter Display Window automatically creates and displays all AF parameters for each device based on the connection status. The AF parameters displayed in this window cannot be edited.

AF	DAB_ATD DAE_C						DAB_CTO DAB_A					
SERVICE	SVC0 DAS DRM V U DAS DAS V U DRM U DRM U DRM U DRM 1 2	5WC1	SVC2	SVC0 DAB DRM DAB DRM DAB DRM DAB DRM DAB DRM DAB DRM	SVC1	SVC2	SYCO DAE	SVC1	5VCZ	SVCD DAB DEM DAB DEM DEM 0 1 2	SVC1	SVC2

Figure 6: Example of DAB/DRM AF Link Connection

AF PJ	NRAM () DOB_A) D	RM_B 🔵 DAB_C 🌑 DRM_D 🎹	AF	PARAM 🕘 DAB_A 🔿 DR	M_B 💿 DAB_C 🕒 DRM_D 🎹	AF PA	RAM 🕘 DAB_A 🍮 D	RM_B 🔘 DAB_C 🔵 DRM_D 🙀	AF P/	VEAM 🕤 DAB_A 🔵 DRI	LB O DAB_C O D	EN_
E) AF	DAB_TO_DAB		8	F_DRM_TO_DRM		D AF	DAB_TO_DAB	^		DRM_TO_DRM		
TH	NUN	1		- NUM	1	-NUN		1		NUR	8	
-	AF		5	E-AF 00			G-AF. 99			SVC_TO_DRM		
	OTHER EID	EGOC HEX		OTHER_FREQ	91,900 MHz		OTHER_EID	E00A HEX		NUH	8	
	OTHER FREQ	174,928 MHz		SYNC MUX	YES		OTHER FREQ	195,936 NH2	B-AF	SVC_TO_RDS		
CEI		LONG TERM	- A	AF_SVC_T0_DRM		CEL		LONG TERM		NUM	8	
AF	SVC_TO_DAB			-NUN 1		E AF	SVC_TO_DAB	1000 million 100 million	E-AF	SVC_TO_DAB		
	NUM	3	B-AF 00		-NUN 1		- NUH	NUH	2			
-	AF 00			TUNED SVC	SERVICE00	E-AF 00			ė.	AF_00		
T	TUNED_SVC	SERVICE00			D003 HEX 91,900 MH2	TUNED SVC		SERVICE00		- TUNED_SVC	SERVICE00	
							OTHER SID	ACO1 HEX		- OTHER_SID	AB01 H	
	OTHER EID			SAME_SERVICE	VES		OTHER EID	EREA HEX		OTHER_FREQ	EU_SA	
	OTHER FRED	THER_FREQ 174.928 MHz		E- AF_SVC_TO_RDS			OTHER FRED	195,936 MHZ		-SAME_SERVICE	YES	
	CEI			NUM			CET	LONG_TERM	ė	AF_01		
	-1.51	1		F SVC TO DAB	2		-LSN	1		- TUNED_SVC	SERVICE01	
	- S/H	HARD LINK	-	- NUN			- S/H	HARD LINK		OTHER_SID	A002 H	EX
	TLS NATIONAL			- AF 00			115	NATTONAL		-OTHER_FREQ	EU_SA	
-	AF 01	TO TABLE IS	TUNED_SVC		SERVICEOO	E- AF	SVC TO RDS			SAME_SERVICE	YES	
	AF_82			OTHER_SID	ARR1 HEX	and the second second	NUM	9				
	SVC TO RDS			OTHER_FREQ	EU SA	and the second	SVC TO DRM					
	NUM	0		SAME_SERVICE	YES		NUM	2				
	SVC TO DRM			AF 01		G-AF_00						
	NN	2		TUNED_SVC	SERVICE00		TUNED_SVC	SERVICEOO				
-	AF 00			OTHER SID	COO2 HEX		OTHER SID	D283 HEX				
	AF 01			OTHER_FREQ	EU SA		OTHER ECC	241				
-	TUNED SVC	SERVICE02		SAME SERVICE	YES		OTHER FRED	91,900 MHZ				
	OTHER SID	DEB3 HEX		A SAL DERVICE			CEI	LONG TERM				
	OTHER ECC	261					-LSN	1				
	OTHER_FREQ	91,900 MHz					S/H	HARD LINK				
	-CEI	LONG TERM				-	AF 01					
	LSN	1				-	- TUNED SVC	SERVICE01				
	S/H	HARD LINK					OTHER SID	8091 HEX				
							OTHER FCC	241 4				

Figure 7: Example of AF Parameter Tree

3. Power Configurator

Power configuration files can be imported into the Power Configurator, or the power level of each transmitter can be set individually. This facilitates simulating various transmitter and radio broadcast signal environments that may occur in real-world situations. All power values are automatically checked and constrained based on the connected devices to ensure the instruments function correctly.



Figure 8: Power Configurator

5. Conclusion

Service Following is an application and test closely aligned with real-world scenarios. Its ultimate goal is to provide users with a better listening experience. To make the actual service more stable and reliable, it is essential to simulate real-world application scenarios as much as possible during testing. Using the RWC2010C, RWC2100F, and supporting test software provided by Doewe Technologies allows the construction of various test scenarios, effectively simulating this process for testing purposes. This provides a convenient test solution for automobile manufacturers and car audio system manufacturers. Readers interested in learning more about the products and solutions can refer to the RWC2010C and RWC2100F product brochures and related materials, or contact our company by phone (+86-10-64327909).